

Audition

D400

D400[™] D400^F

Audition

This guide shows you how to set up the D400 in Audition. All pictures provided were taken with Audition CC 2014 but it is also applicable to most other Audition versions.

All files mentioned in this guide can be found on the USB drive, in the Asparion Configurator installation folder or on our website.

If you are having trouble with anything in this guide, please contact us via our website <u>www.asparion.de/contact</u> and we'll immediately help you.

Step 1:

- Select the Audition preset How to select a preset is described in the main manual.

er

Step 2:

- Open Audition
- Click on Edit->Preferences->Control Surface...



er

Step 3:

- Select Mackie
- Press Configure
- Press Add and select Mackie Control and D400

			Prefe	rences				×
Control Surface			Configure M	ackie Control		×		
Data			comgare	ackie control				
Effects			Carefornico M			×		
Markers & Metadata								
Media & Disk Cache								
Multitrack		Device Type:	Mackie Contr	ol				
Multitrack Clips	MIDI	nput Device:	D 400		•			
Playback	MIDI Ou	tput Device:	D 400		-			
Spectral Displays								
Time Display				OK	Cancel			
					Cancer			

en

Step 4: (optional)

- In the **Button Assignments** window you can select what your buttons should do

		Button Assignmen	ts:		
		Button	Command		
		SMPTE/Beats	View Select the payt	time display format	
		F1	The model care the sec	one applay format	
		Available Host Co	mmande		
		Command		 Description 	
		Analysis.Scan Am	nplitude Statistics	Performs a scan in the arr	iplitude statistics panel.
		Clip Automatic C	routicy Analysis	Toggle whether or not cro	quericy analysis parter.
		Clip.Automatic S	peech Alianment	Alians the speech of one	clip to the speech in another clip.
		Clip.Clip Gain		Set the clip gain using Pro	operties panel.
		Clip.Clip/Group (Shows the Clip Color dial	og for changing the selected clip or group color.
		Clip.Convert to U	Inique Copy	Create new trimmed files	for the selected clips to refer to.
		Clip.Edit Source		Edit the source file which	the selected clip references.

- In the factory preset these are the corresponding keys:

D400	Audition
1-8 (Double click)	F1-F8
Shift	Shift
Metronome	Click
Loop	Loop
assignable 1	Marker
assignable 2	Nudge
*	Save

en

Step 5: (optional)

 If you want to connect more than one extension, you should redo step 2 and 3 but select D400 (2) as MIDI Input and as MIDI Output and Mackie Control XT

If there is only one D400 showing up, you need to enable the extensions first. How you can do that is described in the main manual.

			Preferences				X
		Button Assignment					
				Configu	re Mackie (Control	
			 Type 				
		Mackie Control		×			
				-			
Device Type:	Mackie Cor	ntrol XT	-				
MIDI Janual Davies	MIDUND (D	400)	-				
MIDI Input Device		400)					
MIDI Output Device:	MIDIOUT2	(D 400)	-				
			Cancel				

er



For more information visit www.asparion.de